


How to set 350W router frequency

1. Before power on, press the "RESET" button first, then turn on the 220V power.



2. The screen will display "P1" at the beginning, please select the "P5" mode after pressing the "DOWN" and "UP" keys.



3. Switch mode by "START" key, here we choose "ON" mode (data communication mode). - - - (new version drive select "cn" mode)





4. Press the "RESET" button to save it, and turn off the power supply.



5. Set the "AUTO" mode (automatic mode) and switches the "green key" in the middle of the character.



