The setting method of the opposite optical fiber is as follows

## PRESS THE EMERGENCY BUTTON FIRST!!

1. Set the position of the target sensor to d. Press the L / D button for a short time, and the green character displays (I-on) or (d-on). Long press the L / D button for 5 seconds to switch the display to the d-on state. Release the button for 5 seconds and return to the end setting automatically.



2. Press the set button once when there is no occlusion between the optical fiber heads, and then completely mask the optical fiber head, and press the set button once.



3. After setting, there should be a value when there is no occlusion between the heads, and there should be no value when there is occlusion.