



Remove the board ,only connect the two cable




Find QYKZ wire T+ T- connect to D+ D-
24V connect to solenoid valve wire + , UP connect to UP , ZP connect to ZP

BK3-气源箱气域通讯线BK306Q



BK3-气源箱电磁阀控制线BK305QP



BK3-气源箱电磁阀控制线接线图V1.0.0

